XC60J 快速安装指南【简体中文】

正面构造



F1. USB 3.0 连接端口
F2. USB 2.0 连接端口
F3. 麦克风插孔
F4. 耳机孔
F5. 电源按钮/电源指示灯
F6. 硬盘指示灯
F7. COM6 串行端口 (RS232)
F8. COM7 串行端口 (RS232)
F9. COM8 串行端口 (RS232)

背面构造



B1. 电源插孔 (直流电输入)
B2. 网络连接端口
B3. USB 2.0 连接端口
B4. Kensington® 标准防盗锁孔
B5. D-Sub (VGA) 连接端口
B6. HDMI 连接端口
B7. COM2 串行端口 (RS232)
B8. COM1 串行端口 (RS232/422/485)
B9. COM4 串行端口 (RS232)
B10. COM3 串行端口 (RS232)
B11. 清除 CMOS 钮
B12. COM5 串行端口 (RS232)

COM 串行端口 (COM1_2, COM3_4)



RS232/422/485:
COM1_2 (Down)

1=DCD_485TX-	6=DSR
2=RX_485TX+	7=RTS
3=TX_422RX+	8=CTS
4=DTR_422RX-	9=RI(NA)
5=GND	10=N/C

Only RS232:
COM1_2 (UP) and COM3_4

1=DCD	6=DSR
2=RX	7=RTS
3=TX	8=CTS
4=DTR	9=RI(NA)
5=GND	10=N/C

主机板说明



➢ 安全资讯

请在安装 Shuttle XPC 前阅读以下注意安全信息。

注意 更换电池方式错误可能会损坏本电脑。仅能依 Shuttle 的建议, 以相同或同等的电池更换。
请依照制造商的使用说明处理废电池。

Jumper 设定

J1 LPC 插座 (LPC1)

1=LPC_24M	2=GND
3=LFRAME	4=NULL
5=SIORST-	6=NC
7=LAD3	8=LAD2
9=+3.3V	10=LAD1
11=LAD0	12=GND
13=LPC_48M	14=PCH_PME-
15=+3.3VS	16=SERIRQ
17=GND	18=CLKRUN_NC
19=PD#_NC	20=SUS_CLK_TPM



J2 音效插座 (AUDIO1)

1=MIC_L	2=AGND
3=MIC_R	4=FRONT-JD
5=HP_R_C	6=MIC-JD
7=SENSE B	8=NULL
9=HP_L_C	10=HP-JD



J3 电池插座 (CN1)

1=V_BAT
2=GND

J4 回电自动开启 (JP5)

1=PWRSW-
2=GND



J5 前置 USB 3.0 插座 (USB4)

1=USB30_PWR	2=USB30_PWR	3=USB30_PWR
4=USB30_PWR	5=U3_RX0N	6=U3_RX0P
7=GND	8=GND	9=U3_TX0N
10=U3_TX0P	11=GND	12=GND
13=USB0_N	14=USB0_P	15=USB30_PWR
16=USB30_PWR	17=USB30_PWR	18=USB30_PWR
19=U3_RX1N	20=U3_RX1P	21=GND
22=GND	23=U3_TX1N	24=U3_TX1P
25=GND	26=GND	27=USB2_N
28=USB2_P	29=GND	30=GND

J6 SATA 电源插座 (+5V)(PW2)

1=GND
2=GND
3=+5V
4=+5V

J7 SATA 电源插座 (+12V)(PW1)

1=GND
2=NC
3=+12V

J8 风扇插座 (FAN1)

1=GND
2=+12V
3=SPEED_SENSE
4=PWM_CTRL

J9 前置 USB 2.0 插座 (USB2)

1=USB_PWR	2=USB_PWR
3=USB4_N	4=USB3_N
5=USB4_P	6=USB3_P
7=GND	8=GND
9=NC	10=GND



J10 USB 2.0 插座 (USB3)

1=GND
2=USB1_P
3=USB1_N
4=USB_PWR

J11 电源插座 (SW2)

1=HDLEDPWR	2=PWR_LED
3=SATALED	4=GND
5=RST_SW	6=PWR_SW
7=GND	8=GND
9=NULL	10=NA



J12 COM 串行端口插座(COM5,COM6,COM7,COM8)

1=DCD	2=RX
3=TX	4=DTR
5=GND	6=DSR
7=RTS	8=CTS
9=RI(NA)	10=N/C



J13 COM 电源开关 (JP7,JP8,JP9,JP2) (DEFAULT=SHORT 1-2,3-4) RI(NA)

COM1_2(Down) & COM1_2(Up) POWER SWITCH : JP7

Support RS232 Back panel
Independent External Power 12V / 5V
JUMP1 Connector Pin 1 and Pin 2 = RI1 Signal.
JUMP2 Connector Pin 3 and Pin 4 = RI2 Signal.
IF JUMP1 Connector Pin 5 and Pin 7 = RI1 is VCC
IF JUMP2 Connector Pin 6 and Pin 8 = RI2 is VCC
IF JUMP1 Connector Pin 7 and Pin 9 = RI1 is 12V
IF JUMP2 Connector Pin 8 and Pin 10 = RI2 is 12V



1=-XRI1(NA)	2=COM_-XRI1(NA)
3=-XRI2(NA)	4=COM_-XRI2(NA)
5=+5V	6=+5V
7=COM1_PWR	8=COM2_PWR
9=+12V	10=+12V

COM5 & COM6 POWER SWITCH : JP9

Support RS232 Back panel
Independent External Power 12V / 5V
JUMP1 Connector Pin 1 and Pin 2 = RI5 Signal.
JUMP2 Connector Pin 3 and Pin 4 = RI6 Signal.
IF JUMP1 Connector Pin 5 and Pin 7 = RI5 is VCC
IF JUMP2 Connector Pin 6 and Pin 8 = RI6 is VCC
IF JUMP1 Connector Pin 7 and Pin 9 = RI5 is 12V
IF JUMP2 Connector Pin 8 and Pin 10 = RI6 is 12V



1=-XRI5(NA)	2=COM_-XRI5(NA)
3=-XRI6(NA)	4=COM_-XRI6(NA)
5=+5V	6=+5V
7=COM5_PWR	8=COM6_PWR
9=+12V	10=+12V

COM3_4(Down) & COM3_4(Up) POWER SWITCH : JP8

Support RS232 Back panel
Independent External Power 12V / 5V
JUMP1 Connector Pin 1 and Pin 2 = RI3 Signal.
JUMP2 Connector Pin 3 and Pin 4 = RI4 Signal.
IF JUMP1 Connector Pin 5 and Pin 7 = RI3 is VCC
IF JUMP2 Connector Pin 6 and Pin 8 = RI4 is VCC
IF JUMP1 Connector Pin 7 and Pin 9 = RI3 is 12V
IF JUMP2 Connector Pin 8 and Pin 10 = RI4 is 12V



1=-XRI3(NA)	2=COM_-XRI3(NA)
3=-XRI4(NA)	4=COM_-XRI4(NA)
5=+5V	6=+5V
7=COM3_PWR	8=COM4_PWR
9=+12V	10=+12V

COM7 & COM8 POWER SWITCH : JP2

Support RS232 Back panel
Independent External Power 12V / 5V
JUMP1 Connector Pin 1 and Pin 2 = RI7 Signal.
JUMP2 Connector Pin 3 and Pin 4 = RI8 Signal.
IF JUMP1 Connector Pin 5 and Pin 7 = RI7 is VCC
IF JUMP2 Connector Pin 6 and Pin 8 = RI8 is VCC
IF JUMP1 Connector Pin 7 and Pin 9 = RI7 is 12V
IF JUMP2 Connector Pin 8 and Pin 10 = RI8 is 12V



1=-XRI7(NA)	2=COM_-XRI7(NA)
3=-XRI8(NA)	4=COM_-XRI8(NA)
5=+5V	6=+5V
7=COM7_PWR	8=COM8_PWR
9=+12V	10=+12V

A. 开始安装

⚠ 当你移开机壳时，基于安全考虑请先将电源线拔起。

1. 松开两颗背板手转螺丝。

2. 将机壳往外推出，再向上拿起。



3. 松开支架上的固定螺丝，取下支架。

B. 安装内存模块

⚠ 本主板仅支持 1.35V DDR3L 内存模块。

1. 找到主机板上的 SO-DIMM (DIMM1) 插槽。
2. 将内存缺口对准 DIMM 插槽上的凹槽。
将内存安插于插槽上, 并确认方向是否有误。



3. 将内存以45度角轻轻插入插槽内。
4. 将内存往下压至两侧卡榫完全定位。



5. 请重覆上述步骤安装其余的记忆体于DIMM插槽上。



C. 选配安装 (M.2 SSD/ 硬盘)

1. 如图所示。



2. 将 M.2 SSD 插入 M.2 插槽, 并锁上固定螺丝。

3. 解开电源线的束线带, 以利组装。



4. 将HDD硬盘或SSD固态硬盘放入支架中, 锁紧螺丝。

☛ 适用于 2.5" HDD/SSD



☛ 适用于 3.5" HDD/SSD



5. 安装 SATA 排线与电源线于硬盘插槽。

☛ 适用于 2.5" HDD/SSD



☛ 适用于 3.5" HDD/SSD

6. 将硬盘连同支架装入机壳内，并锁上固定螺丝。

☛ 适用于 2.5" HDD/SSD



☛ 适用于 3.5" HDD/SSD

D. 组装完成

1. 装回上盖并锁上螺丝。

2. 完成。

⚠ 请按"Del"键同时启动, 进入BIOS选项设定, 加载最佳效能的BIOS设定值。

浩鑫股份有限公司　地址：114 台北市内湖区瑞光路76巷30号　电话：886-2-8792-6168

※ 出货机种颜色，以实际出货机种为准。